
950 SUPERMOTO 2005/06
wiring diagramm
main harness - 625.11.075.000
20.02.2005
1/8
rear light/braking light
right rear flasher
licence plate lamp
left rear flasher
diode
diode
diode
regulator-rectifier
generator
light system relay
fuel pump relay
start auxiliary relay
rear brake switch
seat surveillance
over-heat alarm system
antenna
Connector for optional alarm system
alarm system dummy plug
battery
start relay
starter motor
fuel pump
fuse box
ignition switch
light switch
dim/dipping switch
flasher relay
diode
horn
high/low beam switch
horn switch
flasher switch
heated handlement
heated handlement
temperature switch
low coolant monitoring
TPS
Pick-up
ECU
EPC 1
EPC 2
pedestand switch
temperature sensor
ignition coil
rear
front
fuel level sensor
neutral switch 2nd gear
2nd gear
oil pressure sensor
temperature switch
cooling fan
cooling fan
additional current connection ACC2
additional current connection ACC1
speed sensor
multi-func.-digital-speedometer
LED light for optional alarm system
front brake switch
clutch switch
right front flasher
headlight
position light
left front flasher